

Crestron 社の機器およびソフトウェアのコマンドに関しては、下記のものに対応しています。

Category	Name	Join Type	Join Numbers			
			RoomView		Control System	
General Info	Online	Digital	1	In	1	In
	Help Request	Serial	1	In/Out	1	In/Out
	Device ID string	Serial	40	In	40	In
Power	Power On	Digital	5	In/Out	5	In/Out
	Power Off	Digital	6	In/Out	6	In/Out
	Status Message	Serial	5001	In	11	In
Emergency Message	Emergency Alert	Serial	22	In/Out	22	In/Out
	Emergency Message	Analog	22	In/Out	22	In/Out
	Emergency Message Supported	Digital	22	In	22	In
Lamp	Lamp hours Integer	Analog	2	In	2	In
Picture	Brightness Level	Analog	5002	In	32	In
	Contrast Level	Analog	5003	In	33	In
	Brightness Plus	Digital	5109	In/Out	119	In/Out
	Brightness Minus	Digital	5110	In/Out	120	In/Out
	Contrast Plus	Digital	5111	In/Out	121	In/Out
	Contrast Minus	Digital	5112	In/Out	122	In/Out
Audio	Volume	Analog	5012	In	42	In
	Volume Up	Digital	5115	In/Out	125	In/Out
	Volume Down	Digital	5116	In/Out	126	In/Out
	Mute On	Digital	5117	In/Out	127	In/Out
	Mute Off	Digital	5118	In/Out	128	In/Out
	Mute Toggle	Digital	5119	In/Out	129	In/Out
Network	IP Address	Serial	5040	In	50	In
	Subnet Mask	Serial	5041	In	51	In
	Default Gateway	Serial	5042	In	52	In
	DNS Server	Serial	5043	In	53	In
	Mac Address	Serial	5044	In	54	In
	Control System IP Address	Serial	5045	In	55	In
	Control System IP ID	Serial	5046	In	56	In
	Control System Port	Serial	5047	In	57	In
	DHCP Enable	Digital	5210	In	220	In
	DHCP Disable	Digital	5211	In	221	In
Source	Source Select 1	Digital	5070	In/Out	80	In/Out
	Source Select 2	Digital	5071	In/Out	81	In/Out
	Source Select 3	Digital	5072	In/Out	82	In/Out
	Source Select 4	Digital	5073	In/Out	83	In/Out

	Source Select 5	Digital	5074	In/Out	84	In/Out
	Source Select 6	Digital	5075	In/Out	85	In/Out
	Source Select 7	Digital	5076	In/Out	86	In/Out
	Source Select 8	Digital	5077	In/Out	87	In/Out
	Source Select 9	Digital	5078	In/Out	88	In/Out
	Source Select 11	Digital	5080	In/Out	90	In/Out
	Source Select 12	Digital	5081	In/Out	91	In/Out
	Source Select 13	Digital	5082	In/Out	92	In/Out
	Source 1 Name Text	Serial	5070	In/Out	80	In/Out
	Source 2 Name Text	Serial	5071	In/Out	81	In/Out
	Source 3 Name Text	Serial	5072	In/Out	82	In/Out
	Source 4 Name Text	Serial	5073	In/Out	83	In/Out
	Source 5 Name Text	Serial	5074	In/Out	84	In/Out
	Source 6 Name Text	Serial	5075	In/Out	85	In/Out
	Source 7 Name Text	Serial	5076	In/Out	86	In/Out
	Source 8 Name Text	Serial	5077	In/Out	87	In/Out
	Source 9 Name Text	Serial	5078	In/Out	88	In/Out
	Source 11 Name Text	Serial	5080	In/Out	90	In/Out
	Source 12 Name Text	Serial	5081	In/Out	91	In/Out
	Source 13 Name Text	Serial	5082	In/Out	92	In/Out
	Current Source	Serial	5010	In	20	In
<b>Password</b>	Admin Password Enable	Digital	5216	In/Out	226	In/Out
	Admin Password Disabled	Digital	5217	In/Out	227	In/Out
<b>Info - Advanced</b>	Projector Name	Serial	5050	In/Out	60	In/Out
<b>Picture - Advanced</b>	Freeze On	Digital	5105	In/Out	115	In/Out
	Freeze Off	Digital	5106	In/Out	116	In/Out
	Menu	Digital	5150	In/Out	160	In/Out
	Up	Digital	5151	In/Out	161	In/Out
	Down	Digital	5152	In/Out	162	In/Out
	Left	Digital	5153	In/Out	163	In/Out
	Right	Digital	5154	In/Out	164	In/Out
	Exit	Digital	5155	In/Out	165	In/Out
	Enter	Digital	5156	In/Out	166	In/Out
	Keystone Plus	Digital	5176	In/Out	186	In/Out
	Keystone Minus	Digital	5177	In/Out	187	In/Out
	AV Mute Off	Digital	5190	In/Out	200	In/Out
	AV Mute On	Digital	5191	In/Out	201	In/Out